






2. solder
3. component
4. componentmask
5. soldermask
6. plated-drill
7. topsilk
8. bottomsilk
9. topassembly
10. bottomassembly
11. fab












Layer plated-drill



# *Evil Mad Scientist Laboratories*

EE L' I L-


*Making the world a better place, one Evil Mad Scientist at a time.*


Home: [evilmadscientist.com](http://evilmadscientist.com)

Office: [evilmadscience.com](http://evilmadscience.com)

Гәлел рәттәләл

Layer topassembly






There are 5 different drill sizes used in this layout, 240 holes total

Symbol	Diam. (Inch)	Count	Plated?
γ	0.028	28	YES
+	0.030	11	YES
x	0.035	191	YES
o	0.038	6	YES
□	0.125	4	YES

Title: card - Fabrication Drawing  
Author: Kindell H. Oskey  
Date: Wed Mar 5 09:55:04 2008 UTC  
Maximum Dimensions: 3500 mils wide, 2000 mils high



Board outline is the centerline of this 10 mil rectangle - 0.0 to 3500.2000 mils